


# MP2S-CAN: LED & switch description



## Group „A”: information - configuration

### L1: red LED

- information about operating and status of car CAN-Bus;
- presentation function under using time of microswitch PA;

### L2: green LED

- information about status of reading data from car CAN-Bus;

### L3: blue LED

- information about status of charging trailer battery circuit;

### PA: group A switch

- presentation current settings of module;
- setting the program number (change of supported cars group);
- module reset to factory settings (doesn't support any car !);

## Group „B”: operation mode with car CAN-Bus

### L4: red LED

- information about current mode of CAN-Bus (when car is on);

### PB: group B switch

- presentation the current operation mode when CAN-Bus is inactive;
- cyclical change of operating mode (passive > active > event > );

## QUASAR Electronics

✉ Cieslewskich 25k Street  
03-017 Warsaw, Poland  
☎ +48 22 4273141...44  
@ office@quasarelectronics.pl  
🌐 www.quasarelectronics.pl/en

**SERVICE  
OPERATION  
OF MODULE**

Scan or Click:



**!! USE ONLY WHEN REQUIRED !!**