






WH3Q-CS-G8
LONG-OUT




OPTION






	bk	wh	bn	gn	rd	ye	bu	or	pk
DE	schwarz	weiß	braun	grün	rot	gelb	blau	orange	rosa
CZ	černo	bílá	hnědá	zelená	červená	žlutá	modrý	oranžový	růžový
SK	čierny	biely	hnedý	zelený	červený	žltý	modrý	oranžový	ružový
RO	negru	alb	maro	verde	roșu	galben	albastru	portocaliu	roz
GB	black	white	brown	green	red	yellow	blue	orange	pink
PL	czarny	biały	brązowy	zielony	czerwony	żółty	niebieski	pomarańczowy	różowy
UA	чорний	білий	коричневий	зелений	червоний	жовтий	синій	помаранчевий	рожевий





PWM



Action required after connecting / disconnecting trailer!

Diagram illustrating the required actions for connecting and disconnecting a trailer:

- Top Row (Disconnecting):** Shows a truck pulling a trailer. An arrow points to the driver's seat, followed by a "STOP" sign, a horn icon, and a 3-second dwell time (3 s).
- Bottom Row (Connecting):** Shows a truck pulling a trailer. An arrow points to the driver's seat, followed by a "STOP" sign, a horn icon, and three 1-second dwell times (1 s 1 s 1 s).

option:

INFO LED			
 gn			—
 ye		—	